


Safe Filling Procedure from Water Filling Station

Customers must use TasWater’s Public Filling Stations in a responsible and safe manner. Instructions on how to use the Filling Station must always be adhered to and care should be taken when connecting and disconnecting the hose from your container/ tanker and the Water Filling Station.

The picture below provides an example of the hose fittings and connections required for a safe fill of your container/tank.




When filling up from the container’s cam lock, open the cap on the top of the container.



Do not climb on your vehicle, trailer, tank or truck.

When filling from this station, we insist that you connect your hose fitting to the cam lock connection at the filling point with the cam lock connection on your water tank



Any person or user found or identified as misusing TasWater’s Public Filling Stations, or its components, may be disallowed future use and be required to pay for any repairs, or damage or costs attributed or resulting from the misuse or abuse.